

## SE-4020

2/10/40/200A 6/12V Manual Wheel Charger with Engine Start



### Detailed Description:

200A ENGINE START | 40A RAPID CHARGE | 10A MEDIUM CHARGE | 2A CHARGE  
FOR EXTREME ENGINE STARTING, CHARGING & RUGGED USE

- Manual operation must be monitored
- 200A Engine Start high amperage for cranking an engine with a weak or run-down battery
- Timer controlled or continuous operation
- Easy-to-read, color-coded meter
- Heavy-duty transformer
- Temperature overload protection
- Heavy-duty clamps for a solid connection
- 6 ft. power cord and output cables for a total reach of 12 ft.
- Contents: (1) Schumacher SE-4020 (1) owner's manual

### Uses:



## Spec Sheet:

Accessory	Handle Wheels Axle and Axle Caps Foot
Charger Type	Manual Operation
Energy Star	-
Input Current Cont	2.0A 4.5A 10.0A ----
Input Current Int	----
Input Engine Start	30.0A
Input Voltage	120VAC 120V
Output Current Cont	10A 40A 2A ----
Output Current Int	----
Output Engine Start	200A
Output Voltage	6VDC 12VDC 7.2V
Period Type	Year
Rating Agency	UL
RoHS	-
Sell Country	United States of America
Unit Depth	9.87
Unit Height	19.00

Unit Weight	27.30
Unit Width	11.70
Warranty Period	3

## Manuals:

Manual #: 0099001427-R0 for : SE-4020



[Find all manual versions for this Model #](#)